



ALL Fasteners connecting any studs, walls, floor joists, roof rafters or any other wood connection MUST be made using BRASS SCREWS. They MUST NOT be made using ANY kind of Nails. This will prevent failure when towing, and will eliminate rusting and pulling apart.